

FIG. 1

204
216
202
218
220
214
212
208
210




FIG. 2




FIG. 3




FIG. 4

FIG. 5

510



Place your GO CARD on the Web target

508

Assuming you have all this,

- A Web Target from Cubic Corp.
- An internet enabled PC running either Windows 95/98 or Windows NT
- Any available serial port to connect the Web Target to your computer
- Microsoft's Internet Explorer Browser version 4.02 or higher

To use this technology you need to have the following

Welcome to the GO CARD Web Target Demonstration page. These Web pages allow you to interact with your GO CARD over the internet. With them you can check your GO CARD's present value and even add monies to it from a credit card.

GO CARD on the Web

502

504

506

500

GO CARD on the Web

✓ 909

Recharge your GO CARD from a credit card

604

612

Enter the recharge amount here

25.00

— 119 —

Select the type of credit card here

American Express

629

Enter your credit card number here

376198741451029

Enter the expiration date here (mm/yy/yy)

12
1/2001 — 618

609

GO CARD GO...

FIG. 6.

602

卷之三

